


SERRURE VERROU DE PORTE LAVE LINGE BEKO 2805310400

Artikel-Nr.: 2805310400



BESCHREIBUNG

Verrou de porte pour lave linge BEKO

Verou metalflex ZV-446

3 cosses

Se monte sur les appareils suivant:

BEKO LL5002 (7104582000)
BEKO WM801 (7105583200)
BEKO WMB50921 (7107341100)
BEKO WMB51221 (7124141200)
BEKO WMB51221S (7116441100)
BEKO WMB61220S (7116441400)
BEKO WMB61221 (7111141100)

BEKO WMB61221M (7124142000)
BEKO WMB61221S (7105241100)
BEKO WMB61231M (7128941600)
BEKO WMB61231MS (7114241100)
BEKO WMB61421 (7107441100)
BEKO WMB6350SE (7104381500)
BEKO WMB6356SD (7105081600)
BEKO WMB6510K (7101482600)
BEKO WMB71032 (7179981100)
BEKO WMB71221 (7178681300)
BEKO WMB71221C (7106141100)
BEKO WMB71221S (7102041100)
BEKO WMB71232 (7178581100)
BEKO WMB71232PTLC (7178581500)
BEKO WMB71232S (7116541100)
BEKO WMB71241 (7128641300)
BEKO WMB71420 (7111641300)
BEKO WMB71420S (7115341200)
BEKO WMB71421S (7115341100)
BEKO WMB71432 (7100641300)
BEKO WMB71442Bleu (7109341100)
BEKO WMB71442Noir (7111541100)
BEKO WMB71442Rouge (7109441200)
BEKO WMB71632 (7114841200)
BEKO WMB81220MS (7102041200)
BEKO WMB81221M (7178681200)
BEKO WMB81230M (7178582300)
BEKO WMB81231M (7178581900)
BEKO WMB81241 (7177081200)
BEKO WMB81241C (7129241100)
BEKO WMB81242LC (7129241200)
BEKO WMB81242S (7107541100)
BEKO WMB81441LM (7140141500)
BEKO WMB81441LMCB (7102241100)
BEKO WMB81441LMS (7102141100)
BEKO WMB81441MC (7102241200)
BEKO WMB912 (7177084300)
BEKO WMB91241 (7177084200)
BEKO WMB91242 (7177081300)
BEKO WMB91242 (7177083800)
BEKO WMB91242LC (7129241300)
BEKO WMB91242S (7107541200)
BEKO WMB91242S (7107542000)
BEKO WMBF6004C (7102881100)
BEKO WMD15060J (7129782000)
BEKO WMD15080P (7132581500)
BEKO WMD15080PS (7134981100)
BEKO WMD15100P (7132781700)
BEKO WMD15100PBL (7136881100)
BEKO WMD15100PS (7136381200)
BEKO WMD16105 (7154681400)
BEKO WMD16125 (7153381200)
BEKO WMD16125S (7160381100)

BEKO WMD23500T (7126181400)
BEKO WMD24500T (7126681300)
BEKO WMD25060N (7120681500)
BEKO WMD25080N (7113181500)
BEKO WMD25085T (7147181800)
BEKO WMD25100N (7119581600)
BEKO WMD25100T (7119581700)
BEKO WMD25105T (7139281200)
BEKO WMD25105TBL (7147881100)
BEKO WMD25105TS (7147081200)
BEKO WMD25120F (7131181500)
BEKO WMD25121F (7131183100)
BEKO WMD25121FS (7136481200)
BEKO WMD26100T (7112781100)
BEKO WMD26100TS (7127581300)
BEKO WMD26120T (7124381900)
BEKO WMD26120TBL (7150581100)
BEKO WMD26120TS (7128481500)
BEKO WMD26123S (7165281300)
BEKO WMD26125 (7143281700)
BEKO WMD26125S (7165281200)
BEKO WMD26140T (7124481800)
BEKO WMD27110 (7146581400)
BEKO WMD56120 (7127781500)
BEKO WMD56120BL (7128881200)
BEKO WMD56120S (7127881200)
BEKO WMD57102 (7120081300)
BEKO WMD66140S (7150481100)
BEKO WMD67101 (7149181200)
BEKO WMD67101S (7149381100)
BEKO WMD67105 (7146681300)
BEKO WMD67110 (7146582100)
BEKO WMD67120 (7146582000)
BEKO WMD67121 (7141681300)
BEKO WMD67121BL (7149481100)
BEKO WMD67121S (7149581100)
BEKO WMD67125 (7146581200)
BEKO WMD67125S (7163881100)
BEKO WMD67141 (7147981100)
BEKO WMD67141S (7149681100)
BEKO WMD67145 (7154281200)
BEKO WMD68120 (7165081200)
BEKO WMD68120S (7174881100)
BEKO WMD77120 (7145981100)
BEKO WMD78120 (7134381300)
BEKO WMD78120S (7161181200)
BEKO WME8227B (7175681100)
BEKO WME8227B (7175681300)
BEKO WMI71241 (7179281100)
BEKO WMI71241 (7179281700)
BEKO WMI71241 (7179281900)
BEKO WMI71641 (7178381100)
BEKO WML15050 (7143883100)

BEKO WML15050KB (7129788000)
BEKO WML15050KL (7129781800)
BEKO WML15060KL (7129781700)
BEKO WML15065 (7143882000)
BEKO WML15100P (7132781900)
BEKO WML15102 (7132083600)
BEKO WML15105 (7132083400)
BEKO WML15105 (7132087200)
BEKO WML15125 (7164881600)
BEKO WML15125S (7167981100)

FICHE TECHNIQUE

Marque	BEKO
EAN13	3663216009334