

Bouton lave vaisselle Bosch Viva 00612270

Referencia: 00612270



FICHE TECHNIQUE

Marca	BOSCH
EAN13	3663216031670