


Sécurité de porte lave linge Electrolux 1249675131

Référence: 1249675131



DESCRIPTION

Sécurité de porte pour lave linge Electrolux

Référence 1249675131 et 3792030425

914521564/00 - EWF10570W
914522643/00 - EWFM14580W
914522661/00 - EWF147580W
914522665/00 - EWF147480W
914522678/00 - EWF147580W
914522686/00 - EWF147480W
914522694/00 - EWF127570W
914522695/00 - EWF167480W
914522852/00 - EWF147450W
914522904/00 - EWF127450W
914522905/00 - EWF127450W
914522906/00 - EWF127450W
914522907/00 - EWF147450W
914522908/00 - EWF147450W
914522909/00 - EWF147450W
914522912/00 - EWF167480W
914522938/00 - EWF167483W
914522939/00 - EWF167483W
914522940/00 - EWF167483W
914523660/00 - EWF149542W
914523662/00 - EWF149542W
914523663/00 - EWF149542W
914523664/00 - EWF149542W
914523669/00 - EWF129442W

914523676/00 - EWF129442W
 914523680/00 - EWF149542W
 914523684/00 - EWF169547W
 914525593/00 - WAGL6E101
 914526004/00 - WASL1E102
 914526005/00 - WASL2E102
 914526676/00 - WASL1E101
 914526677/00 - WASL2E101
 914529202/00 - EWS10770W
 914529203/00 - EWS12770W
 914529300/00 - EWS12971W
 914529301/00 - EWS14971W
 914604331/00 - EWW167580W
 914604333/00 - EWW127470W
 914604334/00 - EWW147470W
 914604335/00 - EWW127470W
 914604337/00 - EWW147470W
 914604339/00 - EWW147472W
 914605325/00 - WTSL4E101

FICHE TECHNIQUE

Marque	ELECTROLUX
EAN13	3663216044953