

Selecteur 10 positions four Electrolux

Reference: 3570840037



FICHE TECHNIQUE

Brand	ELECTROLUX
EAN13	3663216047817