

Patte de bouton de déverrouillage lave linge Electrolux

Riferimento: 1108268002



FICHE TECHNIQUE

Marca	ELECTROLUX
EAN13	3663216037207