


Filtre mousse sèche linge condensation Candy

Referentie: 40006731A



OMSCHRIJVING

Filtre mousse sèche linge condensation Candy

40006731

Filtre Générique

Convient pour les appareils ci dessous:

31100477 EVOC981ATS EVOC 981AT-S

31100478 EVOC781XA EVOC 781XA

31100486 DYC9914AXS DYC 9914AX-S

31100492 DYC9713AXAUS DYC 9713AX-AUS
31100497 EVOC981AS EVOC 981A-S
31100498 KMEXXL8600L KME-XXL 8600 L
31100501 DYC9913AX30 DYC 9913AX-30
31100503 EVOC981AT01 EVOC 981AT-01
31100504 EVOC970AT01
EVOC 970AT-01
31100505 HADC9913AX47
HADC 9913AX-47
31100515 EVOC8813AB47
EVOC 8813AB-47
31100516 EVOC9813XA47
EVOC 9813XA-47
31100517 EVOC980AT47
EVOC 980AT-47
31100518 DYC9913AXXS
DYC 9913AXX-S
31100519 VHC980ATXXS
VHC 980ATXX-S
31100525 GOC970AT84 GOC 970AT-84
31100528 VHC970AT84 VHC 970AT-84
31100529 DYC9813AXS DYC 9813AX-S
31100550 GCH970NA1TS GCH 970NA1T-S
31100555 HADC9913NA1X47 HADC 9913NA1X-47
31100556 EVOC980NA1T47 EVOC 980NA1T-47
31100557 EVOC9813NA1X47 EVOC 9813NA1X-47
31100571 EVOH970NA1T-84 EVOH 970NA1T-84
31100572 DYH9913NA1X84 DYH 9913NA1X-84
31100617 VTH980NA2T84 VTH 980NA2T-84
31100621 EVOC9813NA147 EVOC 9813NA1-47
31100622 EVOC9813NA2X47 EVOC 9813NA2X-47
31100644 GCH980NA1TS GCH 980NA1T-S
31100665 DYH9913NA2XS DYH 9913NA2X-S
31100668 GVH9913NA2S GVH 9913NA2-S
31100670 GCH981NA2TS GCH 981NA2T-S
31100679 GVH9813NA1S GVH 9813NA1-S
31100682 GCH980NA1T47 GCH 980NA1T-47
31100683 GVH9913NA1X47 GVH 9913NA1X-47
31100684 GVH9913NA2X47 GVH 9913NA2X-47
31100701 GVHD813A1S GVH D813A1-S
31100702 GVHD1013A2S GVH D1013A2-S
31100703 GVHD913A2S GVH D913A2-S
31100707 DNHD813A1XS DNH D813A1X-S
31100708 DNHD913A2XS DNH D913A2X-S
31100710 DMHD1013A2XS DMH D1013A2X-S
31100726 DMHD1013A280 DMH D1013A2-80
31100727 DNHD813A280
DNH D813A2-80
31100731 GVHD913A280
GVH D913A2-80
31100740 SFE82AEA
SFE-82AEA
31100746 GCH990NA1T47

GCH 990NA1T-47
31100747 GVHD913A2X47
GVH D913A2X-47
31100751 DNHD8513AXAUS
DNH D8513AX-AUS
31100753 DNHD813A284
DNH D813A2-84
31100754 ODNHD913A237 ODNH D913A2-37
31100756 GCS991A1TS GCS 991A1T-S
31100757 GCS9101A2TS GCS 9101A2T-S
31100758 GCS91013A2S GCS 91013A2-S
31100759 GCS9913A1S GCS 9913A1-S
31100760 ODMHD1013A2X37 ODMH D1013A2X-37
31100770 GVSD913A2S GVS D913A2-S
31100773 SLHD813A2S SLH D813A2-S
31100774 GVHD813A2S GVH D813A2-S
31100776 LLHD813A2XS LLH D813A2X-S
31100801 SLHD1013A2S SLH D1013A2-S
31100814 SLHD913A2X47 SLH D913A2X-47
31100816 SLHD813A2X47 SLH D813A2X-47
31100852 CSH8A2DE47 CS H8A2DE-47
31100854 CSH10A2DE47 CS H10A2DE-47
31100857 GVSH9A2TCEX47 GVS H9A2TCEX-47
31100858 DXWH9A3TKEX47 DXW H9A3TKEX-47
31100861 GVSH10A2TCEX47 GVS H10A2TCEX-47
31100935 CSH8A1LES CS H8A1LE-S
31100948 GVSHY9A2TCES GVS HY9A2TCE-S
31100963 CS4H7A1DES CS4 H7A1DE-S
31101063 CSH8A2LE47 CS H8A2LE-47

FICHE TECHNIQUE

Merk	CANDY
EAN13	3663216034381