

Pied réglable avant lave vaiselle Electrolux

Referentie: 1173687003



OMSCHRIJVING

Pied réglable avant lave vaisselle Electrolux

Référence 1173687003

Appareils concernés:

91106401000 F78450IM0P F78450IM0P
 91106600700 ESI4620RAX ESI4620RAX
 91106600701 ESI4620RAX ESI4620RAX
 91106900200 ZDN11002XA ZDN11002XA
 91106900201 ZDN11002XA ZDN11002XA
 91106900202 ZDN11002XA ZDN11002XA
 91106900203 ZDN11002XA ZDN11002XA
 91106900204 ZDN11002XA ZDN11002XA
 91106900205 ZDN11002XA
 ZDN11002XA
 91107400300 F78420VI0P
 F78420VI0P
 91107400301 F78420VI0P
 F78420VI0P
 91107400302 F78420VI0P
 F78420VI0P
 91107401300 F78420VI1P
 F78420VI1P
 91107401301 F78420VI1P
 F78420VI1P
 91107401302 F78420VI1P F78420VI1P
 91107500200 ZDV14002FA ZDV14002FA

91107500201 ZDV14002FA ZDV14002FA
 91107500202 ZDV14002FA ZDV14002FA
 91107500203 ZDV14002FA ZDV14002FA
 91107500204 ZDV14002FA ZDV14002FA
 91107500205 ZDV14002FA ZDV14002FA
 91107500400 ESL4300LA ESL4300LA
 91107500401 ESL4300LA ESL4300LA
 91107500402 ESL4300LA ESL4300LA
 91107500403 ESL4300LA ESL4300LA
 91107500404 ESL4300LA ESL4300LA
 91107500405 ESL4300LA ESL4300LA
 91107500406 ESL4300LA ESL4300LA
 91107501000 PVS1550 PVS1550
 91107501001 PVS1550 PVS1550
 91107501002 PVS1550 PVS1550
 91107501003 PVS1550 PVS1550....

FICHE TECHNIQUE

Merk	ELECTROLUX
EAN13	3663216031922