


Boite à produit lave vaisselle Electrolux

Indeks: 50247911006



OPIS

Boite à produit lave vaisselle Electrolux

Référence 50247911006

Appareils compatibles:

91172108500 FAV3430I-W FAV3430I-W
91172108600 FAV3430I-D FAV3430I-D
91173200900 LVA145 LVA145
91174600900 FAV5470I-W FAV5470I-W
91178200800 ASF452 ASF452
91178400100 ASF484 ASF484
91178600600 F64800W F64800W
91183101500 DWS694 DWS694
91183201901 DW695 DW695
91183301800 DW697
DW697
91183301801 DW697
DW697
91183302200 DWS919

DWS919
91183302201 DWS919
DWS919
91183402500 LVS766
LVS766
91184104200 ID6345X ID6345X
91184104500 ESI664K ESI664K
91184104600 ESI664X ESI664X
91184107800 ZOP34X ZOP34X
91184153100 LVI460 LVI460
91184200300 ZTM6825 ZTM6825
91184200301 ZTM6825 ZTM6825
91184201800 ZDM6925N ZDM6925N
91184201900 ZDM6925W ZDM6925W
91184202800 ZKS5620I ZKS5620I
91184300900 ZDM6837 ZDM6837
91184301200 ZDM6837X ZDM6837X
91184301900 ZDS6070X ZDS6070X
91184301901 ZDS6070X ZDS6070X
91184304000 ESI669K ESI669K
91184304100 ESI669X ESI669X
91184701600 IT963WRD IT963WRD
91188200300 LVS563 LVS563
91188200900 FAV42300 FAV42300
91188300400 ASF1631 ASF1631
91188302000 LVS664 LVS664
91188302100 ASF1632 ASF1632
91188400200 ASF1648 ASF1648
91188400300 ASF1649 ASF1649
91188400400 DWS697S DWS697S
91188401000 DWS730 DWS730
91188401100 LVS765 LVS765
91188401200 LVS767 LVS767
91189101200 LVI461 LVI461
91189302400 ZDM6037W
ZDM6037W
91189302500 ZDM6037N
ZDM6037N
91189302600 ZDM6037X
ZDM6037X
91189302700 LVI561N
LVI561N
91189302800 LVI561W
LVI561W
91189302900 ZDM6026W
ZDM6026W
91189303000 ZDM6026N ZDM6026N
91189303400 ZDM6026X ZDM6026X
91189400300 LVI761W LVI761W
91189400400 LVI761N LVI761N
91189400500 LVI761X LVI761X
91189400600 LVI761B LVI761B
91189400700 LVI761V LVI761V

91189400800 LVI761J LVI761J
91189603000 ZDS699EX ZDS699EX
91189603001 ZDS699EX ZDS699EX
91189603400 ZD699ALU ZD699ALU
91189700500 FAV50750VI FAV50750VI
91189700501 FAV50750VI FAV50750VI
91189800500 JSI4465E JSI4465E

FICHE TECHNIQUE

Marka	ELECTROLUX
EAN13	3663216037443