

Diffuseur palier de bras lave vaisselle Electrolux

Indeks: 8996461238017



OPIS

Diffuseur palier de bras lave vaisselle Electrolux

Référence 8996461238017

Appareils compatibles:

91123200000 FAV3020-W FAV3020-W
91123200001 FAV3020-W FAV3020-W
91123201800 FAV4050W FAV4050W
91123205701 FAV5052-W FAV5052-W
91123206001 FAV6060-W FAV6060-W
91123206700 FAV8080-W FAV8080-W
91123207700 FAV6060W FAV6060W
91123207701 FAV6060-W FAV6060-W
91123207900 FAV6050
FAV6050
91123207901 FAV6050-W FAV6050-W
91123210800 ASF660W1
ASF660W1
91123210900 ASF660B1

ASF660B1
91123211000 ASF633H
ASF633H
91123211001 ASF633-
H ASF633-H
91123211100 ASF635 ASF635
91123211101 ASF635-W ASF635-W
91123211200 ASF645 ASF645
91123211300 ASF655 ASF655
91123211400 ASF665W1 ASF665W1
91123212100 ASF666 ASF666
91123214300 ASF651 ASF651
91123214901 FAV6061 FAV6061
91123215001 FAV6050-W FAV6050-W
91123217100 ASF639W ASF639W
91123217101 ASF639-W ASF639-W
91123217200 ASF649W ASF649W
91123218100 ASF655-2 ASF655-2
91123219100 FAV3020-W FAV3020-W
91123219101 FAV3020-W FAV3020-W
91123221200 ASF652W ASF652W
91123221400 ESF640-W ESF640-W
91123221401 ESF640-W ESF640-W
91123221500 ASF663W ASF663W
91123221901 FAV8081 W FAV8081 W
91123224400 ASF647 ASF647
91123224401 ASF647 ASF647
91123224500 ASF657 ASF657
91123224800 F4020 F4020
91123224801 FAV4020-W FAV4020-W
91123224900 F4052W F4052W
91123225000 F4052D F4052D
91123225400 ASF689 ASF689
91123225500 ASF688-W ASF688-W
91123225600 ASF677
ASF677
91123225700 ASF676
ASF676
91123225800 ASF670W
ASF670W
91123225900 ASF670
BRAUN
ASF670 BRAUN
91123227500 FAV5070 W
FAV5070 W
91123227800 FAV6081 W
FAV6081 W
91123227900 FAV6071 W FAV6071 W
91123228000 FAV5071 W FAV5071 W
91123400000 FAV3230I-W FAV3230I-W
91123400001 FAV3230I-W FAV3230I-W
91123407601 FAV3230I-M FAV3230I-M
91123410401 FAV6060I-D FAV6060I-D

91123411401 FAV4230 I D FAV4230 I D
91123411501 FAV4230 I W FAV4230 I W
91123411601 FAV4230 I B FAV4230 I B
91123411700 F3220ID F3220ID
91123411701 FAV3020-D FAV3020-D
91123411800 F3220IW F3220IW
91123411801 FAV3020I-W FAV3020I-W
91123413600 ASI619W ASI619W
91123413601 ASI619-W ASI619-W
91123413700 ASI619B ASI619B
91123414700 ASI619N ASI619N
91123414701 ASI619-N ASI619-N
91123414800 ASI619X ASI619X
91123414801 ASI619-X ASI619-X
91123414900 ASI630 ASI630
91123414901 ASI630-W ASI630-W
91123415000 ASI630B ASI630B
91123415001 ASI630-B ASI630-B
91123415100 ASI640 ASI640
91123415200 ASI640B ASI640B
91123415300 ASI650W1 ASI650W1
91123415400 ASI650B1
ASI650B1
91123428700 GS631-4
GS631-4
91123430100 FAV8081I-M ML
FAV8081I-M ML
91123431700 ESI661K
ESI661K
91123431800 ESI661X
ESI661X
91123432100 FAV5270 V I
FAV5270 V I
91123432200 FAV3270VI FAV3270VI
91123433500 ASI685W ASI685W
91123433600 ASI685N ASI685N
91123438600 ASI640 W ASI640 W
91123438700 ASI640 B ASI640 B
91123438800 ASI640 N ASI640 N
91123439800 FAV5270 I M FAV5270 I M
91123439900 FAV5270 I P FAV5270 I P
91123440800 FAV6281 I W FAV6281 I W
91123440900 FAV6281 I B FAV6281 I B
91123441000 FAV6281 I M FAV6281 I M
91123441100 FAV5271 I B FAV5271 I B
91123441200 FAV5271 I W FAV5271 I W
91123414701 ASI619-N ASI619-N
91123414800 ASI619X ASI619X
91123414801 ASI619-X ASI619-X
91123414900 ASI630 ASI630
91123414901 ASI630-W ASI630-W
91123415000 ASI630B ASI630B
91123415001 ASI630-B ASI630-B

91123415100 ASI640 ASI640
 91123415200 ASI640B ASI640B
 91123415300 ASI650W1 ASI650W1
 91123415400 ASI650B1
 ASI650B1
 91123428700 GS631-4
 GS631-4
 91123430100 FAV8081I-M ML
 FAV8081I-M ML
 91123431700 ESI661K
 ESI661K
 91123431800 ESI661X
 ESI661X
 91123432100 FAV5270 V I
 FAV5270 V I
 91123432200 FAV3270VI FAV3270VI
 91123433500 ASI685W ASI685W
 91123433600 ASI685N ASI685N
 91123438600 ASI640 W ASI640 W
 91123438700 ASI640 B ASI640 B
 91123438800 ASI640 N ASI640 N
 91123439800 FAV5270 I M FAV5270 I M
 91123439900 FAV5270 I P FAV5270 I P
 91123440800 FAV6281 I W FAV6281 I W
 91123440900 FAV6281 I B FAV6281 I B
 91123441000 FAV6281 I M FAV6281 I M
 91123441100 FAV5271 I B FAV5271 I B
 91123441200 FAV5271 I W FAV5271 I W

FICHE TECHNIQUE

Marka	ELECTROLUX
EAN13	3663216038013