

Bague de moulinet lave vaisselle Brandt

Indeks: 31X8357



OPIS

Bague de moulinet lave vaisselle Brandt

Référence 31x8357

Appareils compatibles:

00.402.011.00 GS 15360 LV POSE LIBRE 60 CM
00.402.012.00 GS 15365 LV POSE LIBRE 60 CM
00.402.013.00 GS 15369 LV POSE LIBRE 60 CM
00.402.123.00 GI 55360 LV ENCAST/INT. 60CM
00.402.124.00 GI 55365 LV ENCAST/INT. 60CM
00.402.125.00 GI 55369 LV ENCAST/INT. 60CM
00.402.126.00 GI 52540 LV ENCAST/INT. 60CM
00.402.127.00 GI 52245 LV ENCAST/INT. 60CM
00.402.210.00 GS 17470
LV POSE LIBRE 60 CM
00.402.211.00 GS 17475
LV POSE LIBRE 60 CM
00.402.314.00 GI 57470
LV ENCAST/INT. 60CM
00.402.315.00 GI 57475
LV ENCAST/INT. 60CM
00.402.808.00 GS14250
LV POSE LIBRE 60 CM
00.402.809.00 GS 14255
LV POSE LIBRE 60 CM

00.402.810.00 GS 12240 LV POSE LIBRE 60 CM
00.402.811.00 GS 12245 LV POSE LIBRE 60 CM
00.402.812.00 GS 11140 LV POSE LIBRE 60 CM
2750162000 GIV 704 LV ENCAST/INT. 60CM
2750163000 GI 706 B LV ENCAST/INT. 60CM
2750164000 GS 700 W LV POSE LIBRE 60 CM
2750165000 GS 701 W LV POSE LIBRE 60 CM
2750166000 GS 704 B LV POSE LIBRE 60 CM
2750167000 GS 706 W LV POSE LIBRE 60 CM
2750168000 GI 701 W LV ENCAST/INT. 60CM
2750169000 GI 701 CN N LV ENCAST/INT. 60CM
2750170000 GI 704 W LV ENCAST/INT. 60CM
2750171000 GI 706 W LV ENCAST/INT. 60CM
2750172000 GI 706 CN N LV ENCAST/INT. 60CM
2750173000 GI 708 W LV ENCAST/INT. 60CM
2750174000 GS 704 W LV POSE LIBRE 60 CM
2750176000 GSB 701 W LV POSE LIBRE 60 CM
2750177000 GI 700 W LV ENCAST/INT. 60CM
30HBBRAS1 DW10W LV POSE LIBRE 60 CM
30HBBRAS2 DW10S LV POSE LIBRE 60 CM
30HBBRDD2 DWF031WE1 LV POSE LIBRE 60 CM --
30HBBREX1 DWM100 LV POSE LIBRE 60 CM
30HBCLIL1 F19W LV POSE LIBRE 60 CM
30HBKMASA DW15W LV POSE LIBRE 60 CM --
30HBKMASB DW15X LV POSE LIBRE 60 CM --
30JBBGEX1 DWM2001 LV POSE LIBRE 60 CM
30JBBGGB1 1201DW LV POSE LIBRE 60 CM
30JBBREXA DWM150 LV POSE LIBRE 60 CM --
30JBDHIL1 VW200MI
LV POSE LIBRE 60 CM
30JBSOEX1 CAL60EU1
LV POSE LIBRE 60 CM
30JBSOII1 CALIBRA 60
LV POSE LIBRE 60 CM
30JBSOII2 CALIBRA 70
LV POSE LIBRE 60 CM
30JBSOIIA CALIBRA71 14
LV POSE LIBRE 60 CM --
30JFBGEU1 GS11140 LV POSE LIBRE 60 CM
30JFBRBE1 DW12230 LV POSE LIBRE 60 CM --
30JFBRFFA P2550 LV POSE LIBRE 60 CM
30JFBRFFB P2551 LV POSE LIBRE 60 CM
30JFBRFFC P2553 LV POSE LIBRE 60 CM
30JFBRFFD P2550C LV POSE LIBRE 60 CM
30JFBRFFE P2540 LV POSE LIBRE 60 CM
30JFBRFFF P2540C LV POSE LIBRE 60 CM
30JFBRGB1 DWF041WU LV POSE LIBRE 60 CM
30JFEBAA1 GSB701W LV POSE LIBRE 60 CM
30JFTAAS1 TDX20S/S LV POSE LIBRE 60 CM
30JFTAAS2 TDX20W LV POSE LIBRE 60 CM
30JFTHEx1 TDW20EU1 LV POSE LIBRE 60 CM
30SEBRFFA P3520-2 LV POSE LIBRE 60 CM --
30SEBRFFB P3520C-2 LV POSE LIBRE 60 CM --

30SFBRDD2 DWF361EX1 LV POSE LIBRE 60 CM
 30SFBRDD3 DWF361WE1 LV ENCAST/INT. 60CM --
 30SFBRDD4 DWF361XE1 LV POSE LIBRE 60 CM --
 30SFBREX1 DWE300 LV POSE LIBRE 60 CM
 30SFBREX2 DWE200 LV POSE LIBRE 60 CM --
 30SFBREX3 DWE206 LV POSE LIBRE 60 CM
 30SFBREXA DWE350 LV POSE LIBRE 60 CM --
 30SFBREXB DWE356 LV ENCAST/INT. 60CM --
 30SFBRFFA P3530D LV POSE LIBRE 60 CM
 30SFBRFFB P3531D LV POSE LIBRE 60 CM --
 30SFBRFFC P3534DC LV POSE LIBRE 60 CM
 30SFBRFFE TE42CA LV POSE LIBRE 60 CM
 30SFBRFFF P3540 LAVE VAISSELLE
 30SFBRFFG P3543
 LV POSE LIBRE 60 CM
 30SFBRFFH P4530
 LV POSE LIBRE 60 CM
 30SFBRFFI P4530C
 LV POSE LIBRE 60 CM
 30SFBRFFJ P4530V LV POSE LIBRE 60 CM
 30SFBRFFK TE52CA
 LV POSE LIBRE 60 CM
 30SFBRFFL P3540C.....

FICHE TECHNIQUE

Marka	BRANDT
EAN13	3663216036941