

# Bouton de commande lave vaisselle Whirlpool

**Indeks:** 481241029212



## OPIS

### **Bouton de commande lave vaisselle Whirlpool**

Référence: 481241029212

Couleur: brun

Appareils compatibles:

851153529950 ADP6637BR LAVE-VAISSELLE  
851153529951 ADP6637BR LAVE-VAISSELLE  
851153529952 ADP6637BR LAVE-VAISSELLE  
851153629910 ADP6638BR LAVE-VAISSELLE  
851153629940 ADP6639BR LAVE-VAISSELLE  
851153629941 ADP6639BR LAVE-VAISSELLE  
851153629942 ADP6639BR LAVE-VAISSELLE  
851157029841 ADP4547 LAVE-VAISSELLE  
854273029920 ADP6730BR

LAVE-VAISSELLE  
854273529920 ADP6735BR  
LAVE-VAISSELLE  
854273529929 ADP6735BR  
LAVE-VAISSELLE  
854273529970 ADP6736BR  
LAVE-VAISSELLE  
854273529979 ADP6736BR  
LAVE-VAISSELLE

## FICHE TECHNIQUE

|       |               |
|-------|---------------|
| Marka | WHIRLPOOL     |
| EAN13 | 3663216039676 |