

Poignée de porte inox four IKEA C00312070 481241279412

Indeks: C00312070



OPIS

Poignée de porte four IKEA WHIRLPOOL

Références connues : C00312070 et 481241279412

Se monte sur les appareils suivants :

101.423.82 - 857922401004
10150616FRAMTIDOVBO2S - 857927101504
102.181.74OVB41BFOURIK - 857911216000
20123000 - 857921101511
20123000OVB00W - 857921101510
202.181.78OVC31SFOURIK - 857911429000
202.213.26OVB42SFOURIK - 857911816000
301.230.09OVC40SFOURIK - 857924216000
301.453.94OVB11BFOURIK - 857922615002
301.506.20OVUB01W - 857921501020
301.506.20OVUB01W - 857921501021
30150620 - 857921501022
302.259.13 - 857924253510
401.451.76 - 857922416002
402.002.43OVA41SFOURIK - 857927616000
402.181.77OVC40SFOURIK - 857911416000
402.181.77OVC40SFOURIK - 857911416001

501.230.08FRAMTIDOV10SGB - 857924201510
501.424.17OVB01BFOURIK - 857922601004
501.453.93OVB41BFOURIK - 857922616002
501.506.19OVUB01S - 857921501030
501.506.19OVUB01S - 857921501031
50123008FRAMTIDOV9501230 - 857924201511
50123008OVC10S - 857921301517
50142752 - 857922315500
50142752 - 857922315501
502.181.72OVB11BFOURIK - 857911215000
502.259.12 - 857927153500
601.451.75 - 857922415002
60123003 - 857921115510
602.181.76OVB32BFOURIK - 857911329000
602.181.76OVB32BFOURIK - 857911329001
70123007FRAMTIDOV00S - 857921301506
70123007FRAMTIDOV97012300 - 857924201500
70123007FRAMTIDOV97012300 - 857924201501
70142751 - 857922201500
70142751FRAMTIDOVA01S - 857926901504
70142751OVA01S - 857922201502
702.181.71OVB01BFOURIK - 857911201000
702.259.11 - 857927053500
802.181.75OVB32SFOURIK - 857911129000
802.181.75OVB32SFOURIK - 857911129001
857911016000 - 902.181.70OVA41SFOURIK
857921101500 - OVB00S801.230.02
857921101501 - OVB00S801.230.02
857921115500 - OVB10SGB401.230.04
857921115501 - OVB10SGB401.230.04
857921301500 - OVC00S701.230.07
857921301501 - OVC00S701.230.07
857921301502 - OVC00S701.230.07
857921301503 - OVC00S701.230.07
857921301504 - OVC00S701.230.07
857921301505 - OVC00S701.230.07
857921301510 - OVC10S501.230.08
857921301511 - OVC10S501.230.08
857921301512 - OVC10S501.230.08
857921301513 - OVC10S501.230.08
857921301514 - OVC10S501.230.08
857921301515 - OVC10S501.230.08
857921301516 - OVC10S501.230.08
857921316000 - OVC40SCH301.230.09
857921316001 - OVC40SCH301.230.09
857921429001 - OVC31S901.230.11
857921429002 - OVC31S901.230.11
857921429003 - 901.230.11OVC31SFOURIK
857921501000 - OVUB00S301.230.14
857921501010 - OVUB00W501.230.13
857921516000 - OVUB40SCH001.230.15
857921516020 - OVUB41W901.506.22
857921516021 - 90150622OVUB41WOVENSI

857921516030 - OVUB41S101.506.21
857921615000 - OV9MSGB701.230.12
857921615001 - OV9MSGB701.230.12
857921715000 - OV9MWGB301.282.24
857922401000 - OVB01W101.423.82
857922401001 - OVB01W101.423.82
857922401002 - OVB01W101.423.82
857922401003 - OVB01W101.423.82
857922415000 - OVB11W601.451.75
857922416000 - OVB41W401.451.76
857922529000 - OVB32W201.451.77
857922601000 - OVB01B501.424.17
857922601001 - OVB01B501.424.17
857922601002 - OVB01B501.424.17
857922601003 - OVB01B501.424.17
857922615000 - OVB11B301.453.94
857922615001 - OVB11B301.453.94
857922616000 - OVB41B501.453.93
857922729000 - OVB32B701.453.92
857923001000 - OVB01G801.423.88
857923001001 - OVB01G801.423.88
857923001002 - OVB01G801.423.88
857923015000 - OVB11GGB401.455.53
857923016000 - OVB41GCH901.455.55
857923129000 - OVB32G201.455.54
857924229000 - 901.230.11OVC31SFOURIK
857924229001 - 901.230.11OVC31SFOURIK
857926315000 - OV9M1S001.506.12
857926315001 - OV9M1S001.506.12
857926415000 - OV9M1W801.506.13
857926901500 - OVA01S701.427.51
857926901501 - OVA01S701.427.51
857926901502 - OVA01S701.427.51
857926901503 - OVA01S701.427.51
857927015500 - OVA11S501.427.52
857927015501 - OVA11S501.427.52
857927015502 - OVA11S501.427.52
857927101500 - OVB02S101.506.16
857927101501 - OVB02S101.506.16
857927101502 - OVB02S101.506.16
857927101503 - OVB02S101.506.16
857927115500 - OVB12S901.506.17
857927115501 - OVB12S901.506.17
857927115503 - OVB12S901.506.17
857927115504 - 90150617OVB12S
857927229000 - OVB32S701.506.18

FICHE TECHNIQUE

Marka	IKEA
EAN13	3663216043826