

Support touche lave linge Brandt

Referens: 55X0032



BESKRIVNING

Support touche lave linge Brandt

Référence 55X0032

Appareils compatibles:

1000D/DJ 1000 CLASSIC LLPOSE/L/T ESSOR.FIX
1000TD/DF 1000T LLPOSE/L/T ESSOR.VAR
1000TD/EF 1000T LLPOSE/L/T ESSOR.VAR
1000TD/FF 1000T LLPOSE/L/T ESSOR.VAR
1000VD/DF 1000V LLPOSE/L/T ESSOR.VAR
1000VE/EF 1000V LLPOSE/L/T ESSOR.VAR
1004VOD/DF 1004VO LLPOSE/L/T ESSOR.VAR
1008VED/DF 1008VE LLPOSE/L/T ESSOR.VAR
101TD/DF 101T
LLPOSE/L/T ESSOR.VAR
101TD/EF 101T LLPOSE/L/T ESSOR.VAR
101TD/FF 101T LLPOSE/L/T ESSOR.VAR
1059ECOD/D 1059ECO
LLPOSE/L/T ESSOR.VAR
1061VED/DF 1061VE LLPOSE/L/T ESSOR.VAR
1076D/DF 1076TE LLPOSE/L/T ESSOR.VAR
1076TED/DF 1076TE LLPOSE/L/T ESSOR.VAR
1076TED/EF 1076TE LLPOSE/L/T ESSOR.VAR
1077VED/DF 1077VE LLPOSE/L/T ESSOR.VAR

1077VEE/EF 1077VE LLPOSE/L/T ESSOR.VAR
1086VED/DF 1086VE LLPOSE/L/T ESSOR.VAR
1086VED/EF 1086VE LLPOSE/L/T ESSOR.VAR
109D/DJ 109 LLPOSE/L/T ESSOR.FIX
211AVEFFA SLC863 SL TOP CONDENS.
211AVEFFB SLC863 SL TOP CONDENS.
211AVEFFC SLC864 SL TOP CONDENS.
212AFOEEA SFS-5 SL TOP EVACUAT.
212AFOEEB SFS-5 SL TOP EVACUAT.
212AFOEEC SFS-5 SL TOP EVACUAT.
212AVEFFA SLE463 SL TOP EVACUAT. --
212AVEFFD SLE463 SL TOP EVACUAT.
212AVEFFG SLE463 SL TOP EVACUAT.
231ATHEXC TR708C SL TOP CONDENS.
231AVEFFA SLC900 SL TOP CONDENS
232ATHSGA TD78 SL TOP EVACUAT.
232AVEFFA SVEE851 SL TOP EVACUAT.
232AVEFFB SLE684 SL TOP EVACUAT.
232AVEFFC SLE652 SL TOP EVACUAT.
232AVEFFD SLE684 SL TOP EVACUAT.
232AVEFFE SLE652 SL TOP EVACUAT.
232AVEFFF SLE684 SL TOP EVACUAT.
459D/DKM 459 LLPOSE/L/T ESSOR.FIX
499D/DJ 499 SUPER LADY LLPOSE/L/T ESSOR.FIX
500TD/DF 500T LLPOSE/L/T ESSOR.FIX
501VD/DF 501V
LLPOSE/L/T ESSOR.FIX
501VE/EF 501V LLPOSE/L/T ESSOR.FIX
501VE/FF 501V LLPOSE/L/T ESSOR.FIX
501VE/GF 501V LLPOSE/L/T ESSOR.FIX
502TBD/DB 502TB LLPOSE/L/T ESSOR.FIX
502TD/DF 502T LLPOSE/L/T ESSOR.FIX
502TE/EF 502T LLPOSE/L/T ESSOR.FIX
502TE/FF 502T LLPOSE/L/T ESSOR.FIX
502TE/GF 502T LLPOSE/L/T ESSOR.FIX
502TF/GF 502T LLPOSE/L/T ESSOR.FIX
502TF/HF 502TR LLPOSE/L/T ESSOR.FIX
503TD/DF 503T LLPOSE/L/T ESSOR.FIX
504NEW/DS 504NEW LLPOSE/L/T ESSOR.FIX
504VD/DF 504V LLPOSE/L/T ESSOR.FIX
505ED/DF 505E LLPOSE/L/T ESSOR.FIX
505EE/EF 505E LLPOSE/L/T ESSOR.FIX
505EE/FF 505E LLPOSE/L/T ESSOR.FIX
505EE/GF 505E LLPOSE/L/T ESSOR.FIX
505EF/HF 505E LLPOSE/L/T ESSOR.FIX
505NEW/DS 505NEW LLPOSE/L/T ESSOR.FIX
506TD/DF 506T LLPOSE/L/T ESSOR.FIX
507VD/DF 507V LLPOSE/L/T ESSOR.FIX
508TD/DF 508T LLPOSE/L/T ESSOR.FIX
508TD/EF 508T LLPOSE/L/T ESSOR.FIX
508TD/FF 508T LLPOSE/L/T ESSOR.FIX
508TE/GF 508T LLPOSE/L/T ESSOR.FIX
50BD/DF 50B LLPOSE/L/T ESSOR.FIX

50BE/EF 50B LLPOSE/L/T ESSOR.FIX
50BE/FF 50B LLPOSE/L/T ESSOR.FIX
50BE/GF 50B LLPOSE/L/T ESSOR.FIX
50BF/HF 50B LLPOSE/L/T ESSOR.FIX
5107BIOD/D 5107BIO LLPOSE/L/T ESSOR.VAR
5107BIOE/E 5107BIO LLPOSE/L/T ESSOR.VAR
5108BIOD/D 5108BIO
LLPOSE/L/T ESSOR.VAR
511TD/DF 511T
LLPOSE/L/T ESSOR.FIX
511TE/EF 511T LLPOSE/L/T ESSOR.FIX
511TE/FF 511T LLPOSE/L/T ESSOR.FIX
511TE/IF 511T LLPOSE/L/T ESSOR.FIX
511TF/JF 511T LLPOSE/L/T ESSOR.FIX
513TD/DF 513T LLPOSE/L/T ESSOR.FIX
513TE/EF 513T LLPOSE/L/T ESSOR.FIX
513TE/FF 513T LLPOSE/L/T ESSOR.FIX
513TE/GF 513T LLPOSE/L/T ESSOR.FIX
513TF/HF 513T LLPOSE/L/T ESSOR.FIX
5400TD/DF 5400T LLPOSE/L/T ESSOR.FIX
540TLD/DIT 540TL LLPOSE/L/T ESSOR.FIX
540TLE/EIT 540TL LLPOSE/L/T ESSOR.FIX
542NEW/D 542NEW LLPOSE/L/T ESSOR.FIX
--
542NEWE/E 542NEW LLPOSE/L/T ESSOR.FIX --
550AD/DF 550A LLPOSE/L/T ESSOR.FIX
550AE/EF 550A LLPOSE/L/T ESSOR.FIX
550AE/FF 550A LLPOSE/L/T ESSOR.FIX
552NEW/D 552NEW LLPOSE/L/T ESSOR.FIX
554NEW/D 554NEW LLPOSE/L/T ESSOR.FIX
577CNEW/D 577CNEW LLPOSE/L/T ESSOR.FIX
577NEW/D 577NEW LLPOSE/L/T ESSOR.FIX
579NEW/D 579NEW LLPOSE/L/T ESSOR.VAR
585BD/DF 585B LLPOSE/L/T ESSOR.FIX
585BD/EF 585B LLPOSE/L/T ESSOR.FIX
585BD/FF 585B LLPOSE/L/T ESSOR.FIX
585BE/GF 585B LLPOSE/L/T ESSOR.FIX
587NEW/D 587NEW LLPOSE/L/T ESSOR.VAR
597D/D 597 LLPOSE/L/T ESSOR.FIX
650TLD/DIT 650TL LLPOSE/L/T ESSOR.FIX
650TLE/EIT 650TL LLPOSE/L/T ESSOR.FIX
658D/DKM 658LUXE LLPOSE/L/T ESSOR.FIX
659D/DKM 659LUXE LLPOSE/L/T ESSOR.FIX --
744TD/DF 744T
LLPOSE/L/T ESSOR.VAR
750TD/DF 750T LLPOSE/L/T ESSOR.VAR
750TD/EF 750T LLPOSE/L/T ESSOR.VAR
750TE/EF 750T
LLPOSE/L/T ESSOR.VAR
750VAD/DF 750VA LLPOSE/L/T ESSOR.VAR
750VAE/EF 750VA LLPOSE/L/T ESSOR.VAR
751TD/DF 751T LLPOSE/L/T ESSOR.VAR
752TD/DF 752T LLPOSE/L/T ESSOR.VAR

752TD/EF 752T LLPOSE/L/T ESSOR.VAR
752TE/EF 752T LLPOSE/L/T ESSOR.VAR
756TD/DF 756T LLPOSE/L/T ESSOR.VAR
756TD/EF 756T LLPOSE/L/T ESSOR.VAR
756TE/EF 756T LLPOSE/L/T ESSOR.VAR
757VD/DF 757V LLPOSE/L/T ESSOR.VAR
761VD/DF 761V LLPOSE/L/T ESSOR.VAR --
761VD/EF 761V LLPOSE/L/T ESSOR.VAR
801TD/DF 801T LLPOSE/L/T ESSOR.VAR
801VD/DF 801V LLPOSE/L/T ESSOR.VAR
805TD/DF 805T LLPOSE/L/T ESSOR.VAR
806VD/DF 806V LLPOSE/L/T ESSOR.VAR
806VE/EF 806V LLPOSE/L/T ESSOR.VAR
806VE/FF 806V LLPOSE/L/T ESSOR.VAR
807VD/DF 807V LLPOSE/L/T ESSOR.VAR
808TED/DF 808TE LLPOSE/L/T ESSOR.VAR
808TED/EF 808TE LLPOSE/L/T ESSOR.VAR
809VD/DF 809V LLPOSE/L/T ESSOR.VAR
850SCVD/DF 850SCV LLPOSE/L/T ESSOR.VAR
850TOD/DF 850TO LLPOSE/L/T ESSOR.VAR
851TD/DF 851T LLPOSE/L/T ESSOR.VAR
851TE/EF 851T LLPOSE/L/T ESSOR.VAR
852VD/DF 852V LLPOSE/L/T ESSOR.VAR
853VD/DF 853V LLPOSE/L/T ESSOR.VAR
853VE/EF 853V LLPOSE/L/T ESSOR.VAR
853VE/FF 853V LLPOSE/L/T ESSOR.VAR
854VD/DF 854V
LLPOSE/L/T ESSOR.VAR
855TD/DF 855T LLPOSE/L/T ESSOR.VAR
855TE/EF 855T LLPOSE/L/T ESSOR.VAR
856TOD/DF 856TO
LLPOSE/L/T ESSOR.VAR
858D/DKM 858 LLPOSE/L/T ESSOR.VAR
858VED/DF 858VE LLPOSE/L/T ESSOR.VAR
858VED/EF 858VE LLPOSE/L/T ESSOR.VAR
859D/DKM 859SUPER LLPOSE/L/T ESSOR.VAR --
859ECOD/D 859ECO LLPOSE/L/T ESSOR.VAR
859ECOXD/D 859ECOX LLPOSE/L/T ESSOR.VAR
--
859VD/DF 859V LLPOSE/L/T ESSOR.VAR
863VED/DF 863VE LLPOSE/L/T ESSOR.VAR
864VD/DF 864V LLPOSE/L/T ESSOR.VAR
876TED/DF 876TE LLPOSE/L/T ESSOR.VAR
900TD/DF 900T LLPOSE/L/T ESSOR.VAR
903TD/DF 903T LLPOSE/L/T ESSOR.VAR
903TD/EF 903T LLPOSE/L/T ESSOR.VAR
903TD/FF 903T LLPOSE/L/T ESSOR.VAR
908VED/DF 908VE LLPOSE/L/T ESSOR.VAR
955TD/DF 955T LLPOSE/L/T ESSOR.VAR
955TD/EF 955T LLPOSE/L/T ESSOR.VAR
955TD/FF 955T LLPOSE/L/T ESSOR.VAR
986VED/DF 986VE LLPOSE/L/T ESSOR.VAR
999D/DJ 899 LORD LLPOSE/L/T ESSOR.FIX

B800D/DF B800 LLPOSE/L/T ESSOR.VAR
B800D/EF B800 LLPOSE/L/T ESSOR.VAR
C7450D/DF C7450 LLPOSE/L/T ESSOR.VAR
C7450D/EF C7450 LLPOSE/L/T ESSOR.VAR
C7500D/DF C7500 LLPOSE/L/T ESSOR.VAR
C755D/DF C755 LLPOSE/L/T ESSOR.VAR
C8510D/DF C8510 LLPOSE/L/T ESSOR.VAR
F10D/DE F10D/DE LLPOSE/L/T ESSOR.VAR
F12D/DE F12 LLPOSE/L/T ESSOR.VAR --
F3D/DE F3 LLPOSE/L/T ESSOR.FIX --
F4D/DE F4D/DE
LLPOSE/L/T ESSOR.FIX
F4E/EE F4 LLPOSE/L/T ESSOR.FIX
F5D/DE F5D/DE LLPOSE/L/T ESSOR.FIX
F5E/EE F5 LLPOSE/L/T ESSOR.FIX
K540TLD/DIT K540TL LLPOSE/L/T ESSOR.FIX
K540TLE/EIT K540TL LLPOSE/L/T ESSOR.FIX
P9000D/DF P9000 LLPOSE/L/T ESSOR.VAR
P9000D/EF P9000 LLPOSE/L/T ESSOR.VAR
P9000D/FF P9000 LLPOSE/L/T ESSOR.VAR
SF5S SF5S SL TOP EVACUAT.
SLC828D/DF SLC828 SL TOP CONDENS.
SLC848D/DF SLC848 SL TOP CONDENS.
SLC858D/DF SLC858 SL TOP CONDENS.
SLC858D/EF SLC858 SL TOP CONDENS.
SLE720D/DF SLE720 SL TOP EVACUAT.
SLE732D/DF SLE732 SL TOP EVACUAT.
SLE742D/DF SLE742 SL TOP EVACUAT.
SLE744D/DF SLE744 SL TOP EVACUAT.
SLE750D/DF SLE750 SL TOP EVACUAT.
SLE832D/DF SLE832 SL TOP EVACUAT.
SLE834D/DF SLE834 SL TOP EVACUAT.
SLE842D/DF SLE842 SL TOP EVACUAT.
SLE845D/DF SLE845 SL TOP EVACUAT
SLE850D/DF SLE850 SL TOP EVACUAT.
SLE855D/DF SLE855 SL TOP EVACUAT.
SLE86AD/DF SLE86A SL TOP EVACUAT.
SLG680D/DF SLG680 SL TOP EVACUAT.
STAR2050D/D STAR2050 LLPOSE/L/T ESSOR.FIX --
STAR2080D/D STAR2080 LLPOSE/L/T ESSOR.VAR --
TD48ND/DA TD48N SL TOP EVACUAT.
TD68D/DA TD68 SL TOP EVACUAT.
TK1858D/DCH TK1858 SL TOP CONDENS.
TLF450D/DI TLF450 LLPOSE/L/T ESSOR.FIX
TLF550D/DI TLF550
LLPOSE/L/T ESSOR.FIX
TLF800D/DI TLF800
LLPOSE/L/T ESSOR.VAR
TX108ND/DA TX108N LLPOSE/L/T ESSOR.FIX
TX108NE/EA TX108N
LLPOSE/L/T ESSOR.FIX
TX109D/DA TX109N LLPOSE/L/T ESSOR.FIX
TX138D/DA TX138 LLPOSE/L/T ESSOR.FIX

TX208ND/DA TX208N LLPOSE/L/T ESSOR.FIX
TX208NE/EA TX208N LLPOSE/L/T ESSOR.FIX
TX209ND/DA TX209N LLPOSE/L/T ESSOR.FIX
TX228NE/EA TX228N LLPOSE/L/T ESSOR.FIX
TX229D/DA TX229 LLPOSE/L/T ESSOR.FIX
TX238ND/DA TX238N LLPOSE/L/T ESSOR.VAR
TX238NE/EA TX238 LLPOSE/L/T ESSOR.VAR
TX268D/DA TX268 LLPOSE/L/T ESSOR.VAR
TX268E/EA TX268 LLPOSE/L/T ESSOR.VAR
TX268ND/DA TX268N LLPOSE/L/T ESSOR.VAR
TX308D/DA TX308 LLPOSE/L/T ESSOR.VAR
TX328D/DA TX328 LLPOSE/L/T ESSOR.VAR
TX338D/DA TX338 LLPOSE/L/T ESSOR.VAR
TX368D/DA TX368 LLPOSE/L/T ESSOR.VAR
V10D/DJ V10 SL TOP EVACUAT.
V20D/DJ V20 SL TOP EVACUAT.
WA1025D/DD WA1025 LLPOSE/L/T ESSOR.VAR
WA1026D/DD WA1026 LLPOSE/L/T ESSOR.VAR
WA26D/DCH WA26 LLPOSE/L/T ESSOR.VAR
WA925D/DD WA925 LLPOSE/L/T ESSOR.VAR
WH6402SAD/D WH6402SA LLPOSE/L/T ESSOR.FIX
WH7402SAD/D WH7402SA LLPOSE/L/T ESSOR.VAR
WH8402SAD/D WH8402SA LLPOSE/L/T ESSOR.VAR
Y100D/DJ Y100 YAHALOM LLPOSE/L/T ESSOR.FIX
Y101D/DJ Y101 LLPOSE/L/T ESSOR.FIX --
Y300D/DJ Y300 YAHALOM LLPOSE/L/T ESSOR.FIX
Y400D/DJ Y400 YAHALOM LLPOSE/L/T ESSOR.VAR
Y401D/DJ Y401 LLPOSE/L/T ESSOR.VAR

FICHE TECHNIQUE

Varumärke	VEDETTE
EAN13	3663216038327