# Aube de tambour lave linge Bosch Siemens

**Référence:** 289673







## DESCRIPTION

Aube de tambour lave linge Bosch Siemens

Référence: 00289673

Appareils compatibles:

G1WVD0001A/13 G1WVD0001A
V4380X0EU/01 V4380X0EU L-LINGE SECHANT 1400T INTEGRABLE
V4380X0EU/11 V4380X0EU L-LINGE SECHANT 1400T INTEGRABLE
V4380X0EU/12 V4380X0EU L-LINGE SECHANT 1400T INTEGRABLE
V4380X0EU/13 V4380X0EU L-LINGE SECHANT 1400T INTEGRABLE
V4380X0GB/01 V4380X0GB
V4380X0GB/11 V4380X0GB
V4380X0GB/12 V4380X0GB
V4380X0GB/13 V4380X0GB
Machine a laver-Sech
W4280B0GB/01 W4280B0GB

W4280B0GB/11 W4280B0GB
W4280B1EU/01 W4280B1EU Lave-linges hublot
W4280G0EU/01 W4280G0EU
W4280G0EU/11 W4280G0EU
W4280G1EU/01 W4280G1EU
W4280S0EU/01 W4280S0EU
W4280S0EU/11 W4280S0EU
W4280W0EU/01 W4280W0EU
W4280W0EU/11 W4280W0EU
W4280W0EU/12 W4280W0EU
W4280W0GB/01 W4280W0GB
W4280W0GB/11 W4280W0GB
W4280W1EU/01 W4280W1EU L-LINGE FRONTAL 1000T BLANC
W4380X0EU/01 W4380X0EU
W4380X0EU/11 W4380X0EU
W4380X0EU/12 W4380X0EU
W4380X0GB/01 W4380X0GB
W4380X0GB/11 W4380X0GB
W4380X0GB/12 W4380X0GB
W4380X1EU/01 W4380X1EU L-LINGE FRONTAL INTEGRE 1000T
W4380X1GB/01 W4380X1GB
WD61200/01 WD61200
WD61200/11 WD61200
WD61200/12 WD61200
WD61200/13 WD61200
WD61200DS/11 WD61200DS
WD61200FF/01 WD61200FF LAVE-LINGE SECHANT SOLO 1200T 5KG BB
WD61200FF/11 WD61200FF LAVE-LINGE SECHANT SOLO 1200T 5KG BB
WD61200FF/12 WD61200FF LAVE-LINGE SECHANT SOLO 1200T 5KG BB
WD61200FF/13 WD61200FF LAVE-LINGE SECHANT SOLO 1200T 5KG BB
WD61200FG/01 WD61200FG
WD61200FG/11 WD61200FG
WD61200FG/12 WD61200FG
WD61200FG/13 WD61200FG
WD61200IE/01 WD61200IE
WD61200IE/12 WD61200IE
WD61200IE/13 WD61200IE
WD61200SK/01 WD61200SK
WD61200SK/11 WD61200SK
WD61240FG/01 WD61240FG
WD61240FG/11 WD61240FG
WD61240FG/12 WD61240FG
WD61361/13 WD61361 Lave-linges séchants
WD61380GB/13 WD61380GB
WD61390/01 WD61390
WD61390/11 WD61390
WD61390/12 WD61390
WD61390/13 WD61390
WD61390/17 WD61390
WD61392GB/13 WD61392GB
WD61400DK/01 WD61400DK
WD61400DK/11 WD61400DK
WD61400DK/12 WD61400DK

WD61400DK/13 WD61400DK
WD61400GB/01 WD61400GB
WD61400GB/11 WD61400GB
WD61400GB/12 WD61400GB
WD61400GB/13 WD61400GB
WD61430/01 WD61430 Machine a laver-Sech
WD61430/11 WD61430 Machine a laver-Sech
WD61430/12 WD61430 Machine a laver-Sech
WD61430/13 WD61430 Machine a laver-Sech
WD61430CH/01 WD61430CH Machine a laver-Sech
WD61430CH/11 WD61430CH Machine a laver-Sech
WD61430CH/12 WD61430CH Machine a laver-Sech
WD61430CH/13 WD61430CH
Machine a laver-Sech
WD61430DS/11 WD61430DS
Machine a laver-Sech
WD61430FG/01 WD61430FG MACHINE LAVANTE-SECHANTE 1400 TPM
WD61430FG/11 WD61430FG MACHINE LAVANTE-SECHANTE 1400 TPM
WD61430FG/12 WD61430FG
MACHINE LAVANTE-SECHANTE 1400 TPM
WD61430FG/13 WD61430FG MACHINE LAVANTE-SECHANTE 1400 TPM
WD61480GB/13 WD61480GB
WE61020EU/01 WE61020EU Machine a laver
WE61020EU/11 WE61020EU Machine a laver
WE61020EU/12 WE61020EU Machine a laver
WE61020GB/11 WE61020GB
WE61020GB/12 WE61020GB
WE61021EU/01 WE61021EU L.LINGE FRONT TOUT INT. 1000T JET TRONIC
WE61021GB/01 WE61021GB
WE61221EE/01 WE61221EE
WE61420EU/01 WE61420EU LAVE LINGE 1400 T/M FULL-INTEG
WE61420EU/11 WE61420EU LAVE LINGE 1400 T/M FULL-INTEG
WE61420EU/12 WE61420EU LAVE LINGE 1400 T/M FULL-INTEG
WE61421EU/01 WE61421EU LAVE-LINGE 1400 TPM FULL-INTEG, AAB
WET2820EU/01 WET2820EU L.LINGE SECHANT TOUT INT.1400T
WET2820EU/11 WET2820EU L.LINGE SECHANT TOUT INT.1400T
WET2820EU/12 WET2820EU L.LINGE SECHANT TOUT INT.1400T
WET2820EU/13 WET2820EU L.LINGE SECHANT TOUT INT.1400T
WET2820GB/01 WET2820GB
WET2820GB/11 WET2820GB
WET2820GB/12 WET2820GB
WET2820GB/13 WET2820GB
WFE2020EU/01 WFE2020EU Machine a laver
WFE2020EU/11 WFE2020EU Machine a laver
WFE2020EU/12 WFE2020EU Machine a laver
WFE2020GB/01 WFE2020GB
WFE2020GB/11 WFE2020GB
WFE2020GB/12 WFE2020GB
WFE2021EE/01 WFE2021EE
WFE2021EU/01 WFE2021EU
L.LINGE FRONT TOUT INT. 1000T TURBO JET
WFE2021GB/01 WFE2021GB
WFE2421EE/01 WFE2421EE

WFE2820EU/01 WFE2820EU
WFE2820EU/11 WFE2820EU
WFE2820EU/12 WFE2820EU
WFE2821EU/01 WFE2821EU
WFF1100GB/01 WFF1100GB
WFF1101/01 WFF1101
WFF1101CH/01 WFF1101CH
WFF1101II/01 WFF1101II
WFF1101IL/01 WFF1101IL
WFF1110EE/01 WFF1110EE
WFF1110EE/14 WFF1110EE
WFF1110II/01 WFF1110II
WFF1110II/12 WFF1110II
WFF1110II/14 WFF1110II
WFF1111EE/01 WFF1111EE
WFF1111II/01 WFF1111II
WFF1120GB/12 WFF1120GB
WFF1120GB/14 WFF1120GB
WFF1170/14 WFF1170
WFF117AII/01 WFF117AII
WFF1200GB/01 WFF1200GB
WFF1200GB/12 WFF1200GB
WFF1200GB/14 WFF1200GB
WFF1201GB/01 WFF1201GB
WFF120LGB/01 WFF120LGB
WFF1291/01 WFF1291
WFF1400GB/12 WFF1400GB
WFF1400GB/14 WFF1400GB
WFF140LGB/01 WFF140LGB
WFF147SEU/01 WFF147SEU Lave-linges hublot
WFF147SGB/01 WFF147SGB
WFF1600/01 WFF1600 Machine a laver
WFF1600/11 WFF1600 Machine a laver
WFF1600/12 WFF1600 Machine a laver
WFF1600CH/01 WFF1600CH
Machine a laver
WFF1600CH/11 WFF1600CH Machine a laver
WFF1600DD/01 WFF1600DD Machine a laver
WFF1600EE/01 WFF1600EE Machine a laver
WFF1600FF/01 WFF1600FF Machine a laver
WFF1600FF/11 WFF1600FF
WFF1600FF/12 WFF1600FF Machine a laver
WFF1600FG/01 WFF1600FG Machine a laver
WFF1600FG/11 WFF1600FG Machine a laver
WFF1600IE/01 WFF1600IE Machine a laver
WFF1600II/01 WFF1600II Machine a laver
WFF1600II/09 WFF1600II
WFF1600II/11 WFF1600II
WFF1600II/12 WFF1600II Machine a laver
WFF1600IL/09 WFF1600IL
WFF1600TR/01 WFF1600TR Machine a laver
WFF1640IE/01 WFF1640IE
WFF1640IE/11 WFF1640IE

WFF1780/01 WFF1780
WFF1780/11 WFF1780
WFF1780DD/01 WFF1780DD
WFF1780EE/01 WFF1780EE
WFF1780IE/01 WFF1780IE
WFF1780II/09 WFF1780II
WFF1780II/11 WFF1780II
WFF1780II/12 WFF1780II
WFF1800/01 WFF1800 Machine a laver
WFF1800/11 WFF1800 Machine a laver
WFF1800/12 WFF1800 Machine a laver
WFF1800DD/01 WFF1800DD Machine a laver
WFF1800EE/01 WFF1800EE
Machine a laver
WFF1800FF/01 WFF1800FF
Machine a laver
WFF1800FF/11 WFF1800FF Machine a laver
WFF1800FF/12 WFF1800FF Machine a laver
WFF1800FG/01 WFF1800FG Machine a laver
WFF1800FG/11 WFF1800FG Machine a laver
WFF1800FG/12 WFF1800FG Machine a laver
WFF1800GB/01 WFF1800GB
WFF1800GB/11 WFF1800GB
WFF1800GB/12 WFF1800GB
WFF1800GR/01 WFF1800GR Machine a laver
WFF1800GR/11 WFF1800GR Machine a laver
WFF1800GR/12 WFF1800GR Machine a laver
WFF1800IE/01 WFF1800IE Machine a laver
WFF1800II/09 WFF1800II Machine a laver
WFF1800II/11 WFF1800II Machine a laver
WFF1800SN/01 WFF1800SN Machine a laver
WFF1800TR/01 WFF1800TR Machine a laver
WFF1860/01 WFF1860 Machine a laver
WFF1860EE/01 WFF1860EE Machine a laver
WFF1860IE/01 WFF1860IE Machine a laver
WFF2000/01 WFF2000 Machine a laver
WFF2000/11 WFF2000 Machine a laver
WFF2000/12 WFF2000 Machine a laver
WFF2000CH/01 WFF2000CH Machine a laver
WFF2000CH/11 WFF2000CH Machine a laver
WFF2000CH/12 WFF2000CH Machine a laver
WFF2000DD/01 WFF2000DD Machine a laver
WFF2000DD/11 WFF2000DD Machine a laver
WFF2000EE/01 WFF2000EE Machine a laver
WFF2000FF/01 WFF2000FF Machine a laver
WFF2000FF/11 WFF2000FF
WFF2000FF/12 WFF2000FF Machine a laver
WFF2000FG/01 WFF2000FG Machine a laver
WFF2000FG/11 WFF2000FG
Machine a laver
WFF2000FG/12 WFF2000FG
Machine a laver
WFF2000GB/01 WFF2000GB

WFF2000GB/11 WFF2000GB
WFF2000GB/12 WFF2000GB
WFF2000GB/14 WFF2000GB
WFF2000IE/01 WFF2000IE Machine a laver
WFF2000IE/11 WFF2000IE Machine a laver
WFF2000IE/12 WFF2000IE Machine a laver
WFF2000NL/01 WFF2000NL Machine a laver
WFF2000NL/11 WFF2000NL Machine a laver
WFF2000NL/12 WFF2000NL Machine a laver
WFF2000SN/01 WFF2000SN Machine a laver
WFF2000SN/11 WFF2000SN Machine a laver
WFF2000SN/12 WFF2000SN Machine a laver
WFF2001GB/01 WFF2001GB Lave-linges hublot
WFF200LGB/01 WFF200LGB
WFF2010/01 WFF2010 Machine a laver
WFF2010/11 WFF2010 Machine a laver
WFF2010/12 WFF2010
WFF2020EU/01 WFF2020EU
WFF2030/01 WFF2030 Machine a laver
WFF2030/11 WFF2030 Machine a laver
WFF2030/12 WFF2030 Machine a laver
WFF2030DD/01 WFF2030DD Machine a laver
WFF2030FG/01 WFF2030FG Machine a laver
WFF2030IE/01 WFF2030IE Machine a laver
WFF2030II/09 WFF2030II
WFF2030II/11 WFF2030II
WFF2030II/12 WFF2030II Machine a laver
WFF2030IL/01 WFF2030IL
WFF2030IL/09 WFF2030IL
WFF2030IL/11 WFF2030IL
WFF2030NL/01 WFF2030NL Machine a laver
WFF2030NL/11 WFF2030NL
Machine a laver
WFF2060/01 WFF2060 Machine a laver
WFF2060/11 WFF2060 Machine a laver
WFF2060/12 WFF2060 Machine a laver
WFF2060NL/01 WFF2060NL Machine a laver
WFF2060NL/11 WFF2060NL Machine a laver
WFF2070FG/01 WFF2070FG
WFF2070FG/11 WFF2070FG
WFF2070NL/01 WFF2070NL
WFF2080/01 WFF2080 Machine a laver
WFF2080/11 WFF2080 Machine a laver
WFF2080/12 WFF2080 Machine a laver
WFF2080DD/01 WFF2080DD Machine a laver
WFF2080DD/11 WFF2080DD Machine a laver
WFF2080FG/01 WFF2080FG Machine a laver
WFF2080FG/11 WFF2080FG Machine a laver
WFF2080FG/12 WFF2080FG Machine a laver
WFF2080IE/01 WFF2080IE Machine a laver
WFF2080NL/01 WFF2080NL Machine a laver
WFF2080NL/11 WFF2080NL Machine a laver
WFF2080NL/12 WFF2080NL Machine a laver

WFF2080SN/01 WFF2080SN Machine a laver
WFF2080SN/11 WFF2080SN Machine a laver
WFF2080SN/12 WFF2080SN Machine a laver
WFF2080TR/01 WFF2080TR Machine a laver
WFF2080TR/11 WFF2080TR Machine a laver
WFF2080TR/12 WFF2080TR Machine a laver
WFF2090/01 WFF2090 Machine a laver
WFF2090/12 WFF2090
WFF2200SN/01 WFF2200SN
WFF2200SN/11 WFF2200SN
WFF2200SN/12 WFF2200SN
WFG100A/01 WFG100A
WFG107/01 WFG107
WFG1670IL/01 WFG1670IL
WFG1870IL/01 WFG1870IL
WFG2020GB/01 WFG2020GB
WFG2220GB/01 WFG2220GB
WFG2420GB/01 WFG2420GB
WFG242LGB/01 WFG242LGB
WFG247T/01 WFG247T
WFG2820GB/01 WFG2820GB
WFI2000EU/01 WFI2000EU Machine a laver
WFI2000EU/11 WFI2000EU Machine a laver
WFI2000EU/12 WFI2000EU Machine a laver
WFI2001EU/01 WFI2001EU
WFI2020EU/01 WFI2020EU
WFI2020EU/11 WFI2020EU
WFI2020EU/12 WFI2020EU 1000UpM,Stg.ME1,8Tasten,Aqu.
WFI2021EU/01 WFI2021EU L.LINGE FRONT INT. 1000T BL TURBO JET
WFI2060EU/01 WFI2060EU
WFI2060EU/11 WFI2060EU
WFI2060EU/12 WFI2060EU
WFK1601IE/01 WFK1601IE Lave-linges hublot
WFK1781II/01 WFK1781II
WFK2001/01 WFK2001 Machine a laver
WFK2001FF/01 WFK2001FF Machine a laver
WFK2001FG/01 WFK2001FG Machine a laver
WFK2001IE/01 WFK2001IE Machine a laver
WFK2001II/01 WFK2001II Machine a laver
WFK2002FF/01 WFK2002FF L.LINGE FRONT SOLO 1000T
WFK2031/01 WFK2031 Machine a laver
WFK2031/15 WFK2031 Machine a laver
WFK2031CH/01 WFK2031CH Machine a laver
WFK2031II/01 WFK2031II Machine a laver
WFK2031NL/01 WFK2031NL Machine a laver
WFK2071NL/01 WFK2071NL
WFK2081/01 WFK2081
Machine a laver
WFK2091/01 WFK2091
WFK2200GB/01 WFK2200GB Machine a laver
WFK2200GB/11 WFK2200GB Machine a laver
WFK2200GB/12 WFK2200GB Machine a laver
WFK2201GB/01 WFK2201GB

WFK2201SN/01 WFK2201SN
WFK2280GB/01 WFK2280GB Machine a laver
WFK2281SN/01 WFK2281SN
WFK2290/01 WFK2290
WFK2290/11 WFK2290
WFK2290/12 WFK2290
WFK2291/01 WFK2291
WFK2291NL/01 WFK2291NL
WFK2400/01 WFK2400 Machine a laver
WFK2400/11 WFK2400 Machine a laver
WFK2400/12 WFK2400 Machine a laver
WFK2400AU/01 WFK2400AU Machine a laver
WFK2400AU/12 WFK2400AU Machine a laver
WFK2400FF/01 WFK2400FF Machine a laver
WFK2400FF/11 WFK2400FF Machine a laver
WFK2400FF/12 WFK2400FF Machine a laver
WFK2400FG/01 WFK2400FG Machine a laver
WFK2400FG/11 WFK2400FG Machine a laver
WFK2400FG/12 WFK2400FG Machine a laver
WFK2400NL/01 WFK2400NL Machine a laver
WFK2400NL/11 WFK2400NL Machine a laver
WFK2400NL/12 WFK2400NL Machine a laver
WFK2400SK/01 WFK2400SK Machine a laver
WFK2400SN/01 WFK2400SN Machine a laver
WFK2400SN/12 WFK2400SN Machine a laver
WFK2401AU/01 WFK2401AU Lave-linges hublot
WFK2401FF/01 WFK2401FF L.LINGE FRONT SOLO 1200T
WFK2401FG/01 WFK2401FG Machine a laver
WFK2401SN/01 WFK2401SN
Machine a laver
WFK2401UC/01 WFK2401UC
WFK2430/01 WFK2430 Machine a laver
WFK2430/11 WFK2430 Machine a laver
WFK2430/12 WFK2430 Machine a laver
WFK2430CH/01 WFK2430CH Machine a laver
WFK2430CH/11 WFK2430CH Machine a laver
WFK2430CH/12 WFK2430CH Machine a laver
WFK2430DD/01 WFK2430DD Machine a laver
WFK2430DD/12 WFK2430DD Machine a laver
WFK2430EE/01 WFK2430EE Machine a laver
WFK2430EE/12 WFK2430EE Machine a laver
WFK2430FG/01 WFK2430FG Machine a laver
WFK2430FG/11 WFK2430FG Machine a laver
WFK2430FG/12 WFK2430FG Machine a laver
WFK2430IE/01 WFK2430IE Machine a laver
WFK2430IE/12 WFK2430IE Machine a laver
WFK2430NL/01 WFK2430NL Machine a laver
WFK2430NL/11 WFK2430NL Machine a laver
WFK2430NL/12 WFK2430NL Machine a laver
WFK2431/01 WFK2431 Machine a laver
WFK2431CH/01 WFK2431CH Machine a laver
WFK2431IE/01 WFK2431IE Machine a laver
WFK2431NL/01 WFK2431NL Machine a laver

WFK2450EU/01 WFK2450EU
WFK2450EU/11 WFK2450EU
WFK2450EU/12 WFK2450EU
WFK2451EU/01 WFK2451EU
WFK2460NL/01 WFK2460NL
WFK2470NL/01 WFK2470NL Machine a laver
WFK2470NL/11 WFK2470NL Machine a laver
WFK2471EU/01 WFK2471EU Lave-linges hublot
WFK247ENL/01 WFK247ENL
WFK247PEU/01 WFK247PEU Lave-linges hublot
WFK247Z/01 WFK247Z
WFK247ZCH/01 WFK247ZCH
WFK2681SN/01 WFK2681SN
WFK2690/01 WFK2690
WFK2690/11 WFK2690
WFK2690/12 WFK2690
WFK2690FG/01 WFK2690FG
WFK2690FG/12 WFK2690FG
WFK2690NL/01 WFK2690NL
WFK2690NL/11 WFK2690NL
WFK2690NL/12 WFK2690NL
WFK2690SN/01 WFK2690SN
WFK2690SN/12 WFK2690SN
WFK2691/01 WFK2691
WFK2691FG/01 WFK2691FG
WFK2691NL/01 WFK2691NL
WFK2800/01 WFK2800 Machine a laver
WFK2800/11 WFK2800 Machine a laver
WFK2800/12 WFK2800 Machine a laver
WFK2800FG/01 WFK2800FG Machine a laver
WFK2800FG/11 WFK2800FG Machine a laver
WFK2800FG/12 WFK2800FG Machine a laver
WFK2800GB/01 WFK2800GB Machine a laver
WFK2800GB/11 WFK2800GB Machine a laver
WFK2800GB/12 WFK2800GB Machine a laver
WFK2800NL/01 WFK2800NL Machine a laver
WFK2800NL/11 WFK2800NL Machine a laver
WFK2800NL/12 WFK2800NL Machine a laver
WFK2800SK/01 WFK2800SK Machine a laver
WFK2800SN/01 WFK2800SN Machine a laver
WFK2800SN/12 WFK2800SN Machine a laver
WFK2801/01 WFK2801 Lave-linges hublot
WFK2801FG/01 WFK2801FG Machine a laver
WFK2801GB/01 WFK2801GB
Machine a laver
WFK2801RK/01 WFK2801RK
Machine a laver
WFK2801SN/01 WFK2801SN Machine a laver
WFK2801TR/01 WFK2801TR
Machine a laver
WFK280EEU/01 WFK280EEU
WFK2830/01 WFK2830 Machine a laver
WFK2830/11 WFK2830 Machine a laver

WFK2830/12 WFK2830 Machine a laver
WFK2830CH/12 WFK2830CH Machine a laver
WFK2830NL/01 WFK2830NL Machine a laver
WFK2830NL/11 WFK2830NL Machine a laver
WFK2830NL/12 WFK2830NL Machine a laver
WFK2831/01 WFK2831 Machine a laver
WFK2831CH/01 WFK2831CH Machine a laver
WFK2831NL/01 WFK2831NL Machine a laver
WFK283D/01 WFK283D
WFK2870NL/01 WFK2870NL
WFK2870NL/11 WFK2870NL
WFK2870NL/12 WFK2870NL
WFK287LNL/01 WFK287LNL
WFK2891/01 WFK2891 Lave-linges hublot
WFK2891AU/01 WFK2891AU Lave-linges hublot
WFK2891NL/01 WFK2891NL Lave-linges hublot
WFP2471/01 WFP2471 Lave-linges hublot
WFP2471EU/01 WFP2471EU Lave-linges hublot
WFP2491/01 WFP2491
WFP2831/01 WFP2831 Lave-linges hublot
WFP2831FG/01 WFP2831FG Lave-linges hublot
WFP3090/11 WFP3090
WFP3090/12 WFP3090
WFP3090NL/11 WFP3090NL
WFP3090NL/12 WFP3090NL
WFP3091/01 WFP3091 Machine a laver
WFP3091NL/01 WFP3091NL Machine a laver
WFP309E/01 WFP309E
WFP3200GB/11 WFP3200GB
WFP3200GB/12 WFP3200GB
WFP3201FF/01 WFP3201FF L.LINGE FRONT SOLO 1550T
WFP3201GB/01 WFP3201GB
WFP3230/11 WFP3230
WFP3230/12 WFP3230
WFP3230CH/11 WFP3230CH
WFP3230CH/12 WFP3230CH
WFP3230NL/11 WFP3230NL
WFP3230NL/12 WFP3230NL
WFP3230SN/11 WFP3230SN
WFP3230SN/12 WFP3230SN
WFP3231/01 WFP3231 Machine a laver
WFP3231CH/01 WFP3231CH Machine a laver
WFP3231NL/01 WFP3231NL Machine a laver
WFP3231SN/01 WFP3231SN Lave-linges hublot
WFP3270NL/01 WFP3270NL
WFP3290/01 WFP3290
WFP3290NL/01 WFP3290NL
WFP3300FF/01 WFP3300FF L.LINGE FRONT SOLO 1600 TR BL
WFP3300GB/01 WFP3300GB
WFP3330/01 WFP3330 Lave-linges hublot
WFP3330CH/01 WFP3330CH Lave-linges hublot
WFP3330NL/01 WFP3330NL Lave-linges hublot
WFP3330SN/01 WFP3330SN Lave-linges hublot

WFT2400/01 WFT2400 Machine a laver-Sech
WFT2400/11 WFT2400 Machine a laver-Sech
WFT2400/12 WFT2400 Machine a laver-Sech
WFT2400/13 WFT2400 Machine a laver-Sech
WFT2400DD/01 WFT2400DD Machine a laver-Sech
WFT2400DD/12 WFT2400DD Machine a laver-Sech
WFT2400DD/13 WFT2400DD Machine a laver-Sech
WFT2400DS/11 WFT2400DS
Machine a laver-Sech
WFT2400FF/01 WFT2400FF
LAVE-LINGE SECHANT SOLO 1200T 5KG BB
WFT2400FF/11 WFT2400FF LAVE-LINGE SECHANT SOLO 1200T 5KG BB
WFT2400FF/12 WFT2400FF LAVE-LINGE SECHANT SOLO 1200T 5KG BB
WFT2400FF/13 WFT2400FF LAVE-LINGE SECHANT SOLO 1200T 5KG BB
WFT2400FG/01 WFT2400FG LAVANTE-SECHANTE
WFT2400FG/11 WFT2400FG LAVANTE-SECHANTE
WFT2400FG/12 WFT2400FG LAVANTE-SECHANTE
WFT2400FG/13 WFT2400FG LAVANTE-SECHANTE
WFT2400IE/01 WFT2400IE Machine a laver-Sech
WFT2400IE/12 WFT2400IE Machine a laver-Sech
WFT2400IE/13 WFT2400IE Machine a laver-Sech
WFT2400NL/01 WFT2400NL Machine a laver-Sech
WFT2400NL/11 WFT2400NL Machine a laver-Sech
WFT2400NL/12 WFT2400NL Machine a laver-Sech
WFT2400NL/13 WFT2400NL Machine a laver-Sech
WFT2400SK/01 WFT2400SK Machine a laver-Sech
WFT2400SK/11 WFT2400SK Machine a laver-Sech
WFT2440FG/01 WFT2440FG Machine a laver-Sech
WFT2440FG/11 WFT2440FG Machine a laver-Sech
WFT2440FG/13 WFT2440FG Machine a laver-Sech
WFT2690/01 WFT2690
WFT2690/11 WFT2690
WFT2690/12 WFT2690
WFT2690NL/11 WFT2690NL
WFT2691/01 WFT2691
WFT2691/13 WFT2691
WFT2800GB/01 WFT2800GB Machine a laver-Sech
WFT2800GB/11 WFT2800GB Machine a laver-Sech
WFT2800GB/12 WFT2800GB Machine a laver-Sech
WFT2800GB/13 WFT2800GB Machine a laver-Sech
WFT2806GB/13 WFT2806GB
WFT2830/01 WFT2830 Machine a laver-Sech
WFT2830/11 WFT2830 Machine a laver-Sech
WFT2830/12 WFT2830
Machine a laver-Sech
WFT2830/13 WFT2830 Machine a laver-Sech
WFT2830CH/01 WFT2830CH Machine a laver-Sech
WFT2830CH/11 WFT2830CH
Machine a laver-Sech
WFT2830CH/12 WFT2830CH Machine a laver-Sech
WFT2830CH/13 WFT2830CH Machine a laver-Sech
WFT2830FG/11 WFT2830FG Machine a laver-Sech
WFT2830NL/01 WFT2830NL lave-linge MAXX

WFT2830NL/11 WFT2830NL lave-linge MAXX
WFT2830NL/12 WFT2830NL lave-linge MAXX
WFT2830NL/13 WFT2830NL lave-linge MAXX
WFT2830NL/16 WFT2830NL
WH50081/12 WH50081
WH50161/12 WH50161
WH50280GB/12 WH50280GB
WH50291/01 WH50291
WH50361/12 WH50361
WH50480SN/12 WH50480SN
WH50491/01 WH50491
WH50680GB/01 WH50680GB
WH50880/01 WH50880 Machine a laver
WH50880/11 WH50880
WH50880IE/01 WH50880IE Machine a laver
WH50880IE/11 WH50880IE
WH51080/01 WH51080 Machine a laver
WH51080/11 WH51080
WH51080/12 WH51080
WH51080IE/01 WH51080IE Machine a laver
WH51080IE/11 WH51080IE
WH51080IE/12 WH51080IE
WH51080SN/01 WH51080SN Machine a laver
WH51080SN/11 WH51080SN
WH51080SN/12 WH51080SN
WH51090/01 WH51090 Machine a laver
WH61061/01 WH61061
WH61081/01 WH61081 LAVE LINGE CONFORT 1000 T/M
WH61091/01 WH61091
WH61161/01 WH61161
WH61181SN/01 WH61181SN
WH61190/01 WH61190
WH61190/11 WH61190
WH61190/12 WH61190
WH61191/01 WH61191
WH61361/01 WH61361
WH61381SN/01 WH61381SN
WH61390/01 WH61390
WH61390/11 WH61390
WH61390/12 WH61390 Machine a laver
WH61390SN/01 WH61390SN
WH61390SN/12 WH61390SN Machine a laver
WH61391/01 WH61391
WH6139R/01 WH6139R
WH61481GB/01 WH61481GB
WH61481SN/01 WH61481SN
WH6149C/01 WH6149C Lave-linges hublot
WH71291/01 WH71291
WH71291/17 WH71291
WH71561/01 WH71561
WH71590/11 WH71590
WH71590/12 WH71590
WH71591/01 WH71591

WH7159P/01 WH7159P Lave-linges hublot
WH71680GB/01 WH71680GB
WH71690/01 WH71690
WH71690/17 WH71690
WI61020EU/01 WI61020EU
WI61020EU/11 WI61020EU
WI61020EU/12 WI61020EU
WI61021EU/01 WI61021EU
L.LINGE FRONT INT. 1000T BL TURBO JET
WI61040EU/01 WI61040EU
WI61040EU/11 WI61040EU 1000UpM,Stg.ME1,8Tasten,Aqu.
WI61040EU/12 WI61040EU
WI61041EU/01 WI61041EU
WI61060EU/01 WI61060EU
WI61060EU/11 WI61060EU
WI61060EU/12 WI61060EU
WK61420EU/01 WK61420EU L.LINGE SECHANT TOUT INT.1400T
WK61420EU/11 WK61420EU L.LINGE SECHANT TOUT INT.1400T
WK61420EU/12 WK61420EU L.LINGE SECHANT TOUT INT.1400T
WK61420EU/13 WK61420EU L.LINGE SECHANT TOUT INT.1400T
WK61420GB/01 WK61420GB
WK61420GB/11 WK61420GB
WK61420GB/12 WK61420GB 1400UpM,Stg.VER,8Tasten,H/C
WK61420GB/13 WK61420GB
WM50100GB/01 WM50100GB
WM50110IE/01 WM50110IE
WM50110IE/12 WM50110IE
WM50111IE/01 WM50111IE
WM50120/12 WM50120
WM50121/01 WM50121
WM50200/01 WM50200 Machine a laver
WM50200/12 WM50200 Machine a laver
WM50200GB/01 WM50200GB
WM50200GB/12 WM50200GB
WM50200GB/14 WM50200GB
WM50201GB/01 WM50201GB
WM50210/01 WM50210
WM50300FG/12 WM50300FG
WM50300GB/12 WM50300GB
WM50300GB/14 WM50300GB
WM50300SN/01 WM50300SN
WM50300SN/12 WM50300SN
WM50301GB/01 WM50301GB
WM50430/12 WM50430
WM50431/01 WM50431
WM5047AGB/01 WM5047AGB
WM50601/01 WM50601
WM50800/01 WM50800
WM50800/11 WM50800
WM50800EE/01 WM50800EE
WM50800FF/01 WM50800FF
WM50800FF/11 WM50800FF
WM50800FF/12 WM50800FF

WM50800FG/01 WM50800FG
WM50800IE/01 WM50800IE
WM50800IE/11 WM50800IE
WM50800II/01 WM50800II
WM50800II/09 WM50800II
WM50800II/11 WM50800II
WM50800II/12 WM50800II
WM50800IL/01 WM50800IL
WM50800IL/09 WM50800IL
WM50800SN/01 WM50800SN
WM50900/01 WM50900 Machine a laver
WM50900/11 WM50900 Machine a laver
WM50900FF/01 WM50900FF
WM50900FF/11 WM50900FF
WM50900FF/12 WM50900FF
WM50900FG/01 WM50900FG Machine a laver
WM50900GB/01 WM50900GB
WM50900IE/01 WM50900IE Machine a laver
WM50900IE/12 WM50900IE
WM50900IL/01 WM50900IL Machine a laver
WM50900IL/09 WM50900IL
WM50900IL/11 WM50900IL
WM50900SN/01 WM50900SN
Machine a laver
WM51000/01 WM51000 Machine a laver
WM51000/11 WM51000 Machine a laver
WM51000/12 WM51000 Machine a laver
WM51000FF/01 WM51000FF Machine a laver
WM51000FF/11 WM51000FF Machine a laver
WM51000FF/12 WM51000FF Machine a laver
WM51000FG/01 WM51000FG Machine a laver
WM51000FG/11 WM51000FG Machine a laver
WM51000FG/12 WM51000FG Machine a laver
WM51000GB/01 WM51000GB
WM51000GB/11 WM51000GB
WM51000GB/12 WM51000GB
WM51000GB/14 WM51000GB
WM51000GR/01 WM51000GR Machine a laver
WM51000GR/11 WM51000GR Machine a laver
WM51000GR/12 WM51000GR Machine a laver
WM51000IE/01 WM51000IE Machine a laver
WM51000IE/11 WM51000IE Machine a laver
WM51000IE/12 WM51000IE Machine a laver
WM51000SN/01 WM51000SN Machine a laver
WM51000SN/11 WM51000SN Machine a laver
WM51000SN/12 WM51000SN Machine a laver
WM51020EU/01 WM51020EU Machine a laver
WM51020EU/11 WM51020EU Machine a laver
WM51020EU/12 WM51020EU Machine a laver
WM51030/01 WM51030
WM51030/11 WM51030 Machine a laver
WM51030/12 WM51030
WM51030CH/01 WM51030CH

WM51030CH/11 WM51030CH Machine a laver
WM51030CH/12 WM51030CH
WM51030FG/01 WM51030FG
WM51030FG/11 WM51030FG
Machine a laver
WM51030IE/01 WM51030IE
WM51030IE/11 WM51030IE Machine a laver
WM51030II/01 WM51030II
WM51030II/09 WM51030II
WM51030II/11 WM51030II
WM51030II/12 WM51030II
WM51070/01 WM51070
WM51070/11 WM51070
WM51070/12 WM51070
WM51070FG/01 WM51070FG
WM51100SN/01 WM51100SN
WM51100SN/11 WM51100SN
WM60801IE/01 WM60801IE
WM61001/01 WM61001 Machine a laver
WM61001FF/01 WM61001FF Machine a laver
WM61001FG/01 WM61001FG LAVE LINGE CONFORT 1000 T/M CL A/A
WM61001IE/01 WM61001IE Machine a laver
WM61001II/01 WM61001II Machine a laver
WM61002FF/01 WM61002FF LAVE-LINGE FRONT 1000T/MN
WM61031/01 WM61031 Machine a laver
WM61031CH/01 WM61031CH Machine a laver
WM61031FG/01 WM61031FG Lave-linges hublot
WM61031II/01 WM61031II Machine a laver
WM6107BEU/01 WM6107BEU
WM61101GB/01 WM61101GB
WM61200/01 WM61200 Machine a laver
WM61200/11 WM61200 Machine a laver
WM61200/12 WM61200 Machine a laver
WM61200FF/01 WM61200FF Machine a laver
WM61200FF/11 WM61200FF Machine a laver
WM61200FF/12 WM61200FF Machine a laver
WM61200FG/01 WM61200FG Machine a laver
WM61200FG/11 WM61200FG Machine a laver
WM61200FG/12 WM61200FG
Machine a laver
WM61200GB/01 WM61200GB
Machine a laver
WM61200GB/11 WM61200GB Machine a laver
WM61200GB/12 WM61200GB
Machine a laver
WM61200SK/01 WM61200SK Machine a laver
WM61200SN/01 WM61200SN Machine a laver
WM61200SN/12 WM61200SN Machine a laver
WM61201FF/01 WM61201FF L.LINGE FR FUZZY 60 SOLO 1200T BL
WM61201FG/01 WM61201FG
WM61201GB/01 WM61201GB
WM61201SN/01 WM61201SN
WM61230/01 WM61230 Machine a laver

WM61230/11 WM61230
WM61230/12 WM61230
WM61230CH/01 WM61230CH Machine a laver
WM61230CH/11 WM61230CH
WM61230CH/12 WM61230CH
WM61230FG/11 WM61230FG
WM61230FG/12 WM61230FG
WM61230IE/01 WM61230IE Machine a laver
WM61230IE/12 WM61230IE
WM61231/01 WM61231 Machine a laver
WM61231CH/01 WM61231CH Machine a laver
WM61231IE/01 WM61231IE Machine a laver
WM61250EU/01 WM61250EU
WM61250EU/11 WM61250EU
WM61250EU/12 WM61250EU
WM61251EU/01 WM61251EU
WM61270FG/01 WM61270FG
WM61270FG/11 WM61270FG
WM61270FG/12 WM61270FG
WM61271EU/01 WM61271EU Lave-linges hublot
WM61272/01 WM61272
WM61272/15 WM61272 Lave-linges hublot
WM6127BEU/01 WM6127BEU
Lave-linges hublot
WM6127BGB/01 WM6127BGB
WM6127WEU/01 WM6127WEU Lave-linges hublot
WM6127ZCH/01 WM6127ZCH
Lave-linges hublot
WM6137FEU/01 WM6137FEU
WM61400/01 WM61400 Machine a laver
WM61400/11 WM61400 Machine a laver
WM61400/12 WM61400 Machine a laver
WM61400FG/01 WM61400FG Machine a laver
WM61400FG/11 WM61400FG Machine a laver
WM61400FG/12 WM61400FG Machine a laver
WM61400SK/01 WM61400SK Machine a laver
WM61400SN/01 WM61400SN Machine a laver
WM61400SN/12 WM61400SN Machine a laver
WM61401/01 WM61401 Lave-linges hublot
WM61401FG/01 WM61401FG LAVE LINGE CONFORT 1400 T/M CL A/A
WM61401GB/01 WM61401GB
WM61401RK/01 WM61401RK Machine a laver
WM61401SF/01 WM61401SF Lave-linges hublot
WM61401SN/01 WM61401SN Machine a laver
WM61401TR/01 WM61401TR Machine a laver
WM61430/01 WM61430 Machine a laver
WM61430/11 WM61430 Machine a laver
WM61430/12 WM61430 Machine a laver
WM61430CH/01 WM61430CH Machine a laver
WM61430CH/12 WM61430CH Machine a laver
WM61430FG/11 WM61430FG Machine a laver
WM61431/01 WM61431 Machine a laver
WM61431CH/01 WM61431CH Machine a laver

WM61431FG/01 WM61431FG Lave-linges hublot
WM6143H/01 WM6143H
WM61471NL/01 WM61471NL
WM6147E/01 WM6147E Machine a laver
WM6147EEU/01 WM6147EEU
Lave-linges hublot
WM6147EGB/01 WM6147EGB
WM6147ENL/01 WM6147ENL Lave-linges hublot
WM6147SEU/01 WM6147SEU
WM71211/01 WM71211
WM71271EU/01 WM71271EU LAVE LINGE 1200 T/M-IQ-SILENCE CL A/A
WM71401SN/01 WM71401SN
WM71431/01 WM71431 Lave-
linges hublot
WM71431FG/01 LAVE LINGE 1400 T/M-IQ-AQUASTOP CL A/A
WM71630/11 WM71630
WM71630/12 WM71630
WM71630CH/11 WM71630CH
WM71630CH/12 WM71630CH
WM71630FG/11 WM71630FG
WM71630FG/12 WM71630FG
WM71630SN/11 WM71630SN
WM71630SN/12 WM71630SN
WM71631/01 WM71631 Machine a laver
WM71631CH/01 WM71631CH Machine a laver
WM71631FG/01 WM71631FG L.LINGE FR FUZZY 60 SOLO 1550T BL
WM71631SN/01 WM71631SN Lave-linges hublot
WM71670NL/01 WM71670NL
WM71700FF/01 WM71700FF L.LINGE FRONT FUZZY 60 SOLO 1600 TR BL
WM71730/01 WM71730 Lave-linges hublot
WM71730CH/01 WM71730CH Lave-linges hublot
WM71730FG/01 WM71730FG LAVE LINGE 1600 T/M IQ CL AAA AQUASTOP
WM71730SN/01 WM71730SN Lave-linges hublot
WT100010/01 WT100010
WT100010/13 WT100010
WT200-010/13 WT200-010
WXM100A/01 WXM100A
WXM1060/01 WXM1060
WXM1060EE/01 WXM1060EE
WXM106F/01 WXM106F
WXM107/01 WXM107
WXM110GB/01 WXM110GB
WXM1260/01 WXM1260
WXM126F/01 WXM126F
WXM135S/01 WXM135S
WXM140A/01 WXM140A
WXM140GB/01 WXM140GB
WXM1460/01 WXM1460 Lave-linges hublot
WXM1460EU/01 WXM1460EU LAVE-LINGE, 1400TPM, 5KG, LABEL AAB
WXM1460SN/01 WXM1460SN
WXM860EE/01 WXM860EE

## FICHE TECHNIQUE

| | |
|---|---|
| **Marque** | SIEMENS |
| **EAN13** | 3663216040030 |